


FiberLuminator™ RND

RND Track Installation Manual

IMPORTANT SAFETY INSTRUCTIONS
READ AND FOLLOW ALL INSTRUCTIONS
SAVE THESE INSTRUCTIONS



⚠ WARNING

Read and follow all warning notices and instructions accompanying this product. Failure to follow safety warnings and instructions can result in severe injury, death, or property damage. Call (800) 831-7133 for additional free copies of these instructions.

Important Notice



Attention Installer.

This manual contains important information about the installation, operation and safe use of this product. This information should be given to the owner/operator of this equipment.

Instructions for RND Track Installation.

A. New Pools

1. Install your above ground pool as stated in their installation instructions, until you reach the point to install the liner interlocks. See Figure 1.





Figure 1.

2. Instead of installing the liner interlock, clip the RND track over the liner and pool wall as shown in Figure 2.



NOTE
Be sure the thickness of the pool wall and overlapping liner is no more than 0.1 in. thick.

Figure 2.

3. Continue installing the above ground pools as in your above ground pool installation instructions, starting with the wall channel.

B. Retrofit Installations

1. Unless stated by the manufacturer of your above ground pool, drain the water completely out of your pool.
2. Do one section at a time. Remove the top rail coping. Be sure to remember where each screw goes.
3. Remove the top clip and support brackets. Be sure to remember where each screw goes.
4. Remove the wall channel and liner interlocks.
5. Install RND track as shown in Figure 2.

SAVE THESE INSTRUCTIONS.